

Part Number	Male or Female	Compression or Crimp	Wire Type	AWG	Ohms
0E-BNC2P59PT	Male	Crimp	RG58 PVC RG59 PLENUM	20-22	50
0E-BNC2UTP	Male	Crimp	RG59,6 PVC	18-22	50
0E-BNC3PC75T	Male	Crimp	MINI COAX	N/A	75
0E-BNC59PTOT	Male	Twist-On	RG58 PVC R59 PLENUM	20-22	50
0E-BNCC59P75	Male	Compression	RG59 PLENUM	22	75
0E-BNCC6P75T	Male	Compression	RG6 QUAD PLENUM	18	75
0E-BNCCOM75C	Male	Compression	RG59 PVC	20	75
0E-BNCCOM75T	Male	Compression	RG59 PVC	22-18	75
0E-BNCCOMPTP	Male	Compression	RG59 PVC, RG62 PVC	18-22	50
0E-BNCCRI75C	Male	Crimp	RG58 PVC RG59,6 PVC & PLENUM	18-22	75
0E-BNCCRIMPT	Male	Crimp	RG58 PVC RG59,6 PVC & PLENUM	18-22	50
0E-BNCF2P59T	Female	Crimp	RG59 PVC RG6 PLENU	18-22	50
0E-BNCF75TP	BNC Female	N/A	Adapter(no wire)	N/A	75
0E-BNCFFTP	BNC Female	N/A	Adapter(no wire)	N/A	50
0E-BNCFRCAMT	BNC Female to RCA male	N/A	Adapter(no wire)	N/A	50
0E-BNCFUTP	Female	Crimp	RG58 PVC RG59,6 PVC/PLENUM	18-22	50
0E-BNCM25TP	Male	Crimp	RG59 PVC,6 TFE	18-22	50
0E-BNCM2FFTP	BNC Male to F Female	N/A	Adapter(no wire)	N/A	50
0E-BNCM22FTP	BNC Male to Dual BNC Female	N/A	Adapter(no wire)	N/A	50
0E-BNCM2RFTP	BNC Male to RCA Female	N/A	Adapter(no wire)	N/A	50
0E-BNCM5962T	Male	Crimp	RG59,62,140,210 PVC	20-22	50
0E-BNCM59PTP	Male	Crimp	RG58,59 PVC RG59 PLENUM	20-22	50
0E-BNCMC59PT	Male	Compression	RG59 PLENUM	22	50
0E-BNCMC6TP	Male	Compression	RG6 QUAD PLENUM	18	50
0E-BNCT56PTP	Male	Twist-On	RG59 PVC RG6 PLENUM	18-22	50
0E-BNCU75TP	Male	Crimp	RG58 PVC RG59,6 PVC & PLENUM	18-22	75
0E-BNCUNI59T	Male	UNICRIMP	RG59	20	75
0E-FBJTP	F Female to Female	N/A	Adapter(no wire)	N/A	N/A
0E-FC6QTP	Male	Compression	RG6 QUAD SHIELD	18	50
0E-FC6TP	Male	Compression	RG6 PVC	18	50
0E-FCTP	Male	Compression	RG59 PVC	20	50
0E-FFRCAMTP	F Female to RCA male	N/A	Adapter(no wire)	N/A	N/A
0E-FH59TP	F male	HEX Crimp	RG59 PVC	20	50
0E-FH6QTP	F male	HEX Crimp	RG6 Quad shield	18	50
0E-FH6TP	F male	HEX Crimp	RG6 PVC	18	50
0E-FR6TTP	F male	Radial Crimp	RG6 Tri-shield	18	50